



Operator's Product HandBook

FirePatrol14™ & FirePatrol15™

Water Cartage Tanks



“HELPING TO DEVELOP AND PROTECT THE LAND”

Contents

Safety	4
General Safety Instructions	5
General Information	6
Specifications	6
Description	7
Machine Limitations	9
Driving Stability	9
Operating Instructions	9
Before First Use	9
Pump Operation – Petrol Engine	11
Pump Operation – Diesel Engine Option	12
Filling the Tank	12
FirePatrol™ Operation	15
Risk Assessment	19
Maintenance	20
Periodic Checks	20
Maintenance	20
Maintenance Schedule	21
Trouble Shooting	24
Warranty	25
Warranty Policy	25
What this Warranty Does Not Cover?	25
How to Obtain Service Under this Warranty?	25
Warranty Limitations	25

Disclaimer

All information, illustrations, and specifications contained in this manual are based on the latest product information available at the time of this publication's printing. TransTank International (TTi) reserves the right to alter and substitute specifications and methods at any time, in line with our commitment to continuous improvement.

No patent liability is assumed with respect to the use of information contained within this manual. While every precaution has been taken in the preparation of this manual, TTI assumes no responsibility for errors or omissions.

**Thank you for purchasing a FirePatrol[™] Heavy-Duty Trailer Unit,
which will provide many years of reliable service when operated and
maintained in accordance with this manual.**

TTi manufacture a range of FirePatrol[™] units, from 800 through to 3,000 litre tanks, supplied with petrol or diesel pump options. This manual describes the operation, driving stability and maintenance procedures applicable to all units, noting additional requirements to options where necessary.

All TTI FirePatrol[™] tanks are rotationally moulded from quality polyethylene, purpose designed and manufactured to high standards. The FirePatrol[™] is a trailer-mounted tank water dispensing system designed for firefighting, tree watering and similar manually conducted watering activities. With the optional single or dual deflector system fitted, the FirePatrol[™] can be used for dust suppression on unmade roads, construction sites, etc.

The FirePatrol[™] unit is supplied complete, tested and ready to go. TTI recommends that only water be used in the FirePatrol[™] unit. TTI warrants that the FirePatrol[™] has been designed and built for its intended purpose for firefighting and dispensing water, such as tree watering. With the optional deflector system, it can be used as a dust suppression system too.

The owner is responsible to ensure that the equipment is operated in accordance with this manual, with Australian WorkSafe requirements, applicable road rules and local council regulations. TTI is not liable for any loss, injury or death resulting from the failure to observe all safe working regulations as required by law.

Included with your FirePatrol[™] unit is the following documents:

- Operator's Handbook (this manual, which includes the Warranty Registration Card)
- Integral Honda Petrol or Yanmar Diesel engine and pump manufacturer's handbook (whichever option selected)
- Tank Quality Check Form. This is your verification that the unit has been quality checked, and verifies the serial number affixed to the unit.

Safety

This manual is intended for use by personnel experienced in the use of this and similar equipment. Read and understand this manual before attempting to operate or perform routine maintenance on this equipment. Your safety is of prime priority.



A WARNING highlights an essential operating or maintenance procedure, practice, condition or statement, which, if not strictly observed, could result in injury or death of personnel, or long-term health hazards.



A CAUTION highlights an essential operating or maintenance procedure, practice, condition or statement, which, if not observed, could result in damage or destruction of equipment.



A NOTE highlights or clarifies an essential systems description, operating or maintenance procedure, condition or statement.

General Safety Instructions

1. This unit is designed and manufactured solely for the purpose of carrying and pumping water for firefighting, tree watering and optional dust suppression duties. Under no circumstances should it be used for any other purpose. It must never be used for transporting fuel or chemicals.
2. Only authorised and trained personnel are to operate this equipment. Operators must have read and fully understood this manual before operating the Storm unit.
3. Do not operate this equipment while under the influence of alcohol or any drugs that could impair your capabilities in any way.
4. Personal Protection Equipment (PPE) must be worn when refuelling the or operating the pump on the FirePatrol™. Exposure to excessive noise over an extended period can cause impairment or loss of hearing.
5. Avoid diesel or unleaded petrol contact with skin and eyes, and avoid breathing vapours or mists. Refer to the relevant Safety Data Sheet (SDS).
6. Any spillage of fuel while refilling the pump engine's tank should be immediately cleaned up and the materials used in the clean-up disposed of safely and in accordance with relevant regulations applying to the safe use, storage and disposal of fuel.
7. Disconnect the battery, if fitted, before conducting any electrical maintenance work.
8. Ensure the capacity of the vehicle is suitable for the loaded mass of the FirePatrol™. Refer to the vehicle's operator manual for safe working loads and relevant safety instructions. Do not exceed the carrying and braking capacity as specified by the vehicle manufacturer.
9. Ensure the tow vehicle is equipped with a 7-pin plug, with the AUX pin wired for 12-volt power. This pin connects to the brake safety unit.
10. The FirePatrol™ must never be left unattended while being filled with water.
11. Do not operate the pump when there is no water in the tank.
12. Do not disconnect any hoses, nozzles or filters while the equipment is operating. Disconnecting any components while under pressure may result in uncontrolled water discharge which may be hazardous.
13. Care should be taken at all times, particularly when operating on rough or steep terrain. Drivers should be aware of fluid surge affecting the centre of gravity.
14. The FirePatrol™ has safety labels affixed to various locations on the unit. These labels should be kept clean and legible, and replaced if damaged.
15. Any unauthorised modifications to this equipment may affect its function and create a serious safety risk. Any unauthorised modifications will void any warranty on the unit.

General Information

Specifications

Tank	UV resistant polyethylene tank (800 to 3,000 litre capacity), complete with LiquidLocker™ Baffle Safety System
Trailer	Fully welded and galvanised heavy duty steel frame, single or dual axle with 15" Sunraysia wheels with 6-stud pattern
Standard Equipment	LiquidLocker™ Baffle Safety System
	Honda Petrol pump
	36m 19mm fire hose reel with adjustable nozzle
	Pressure regulator
	Open funnel for stand pipe fill
	Tank bottom fill kit via integral pump
Options	Single and dual deflector spray head options
	Solenoid operation of dual deflector spray head option
	Braked or unbraked trailer options
	Hydraulic or electric brake options
	Sight level tube
	Yanmar Diesel engine pump upgrade option
	Electric start on engines (with solenoid operated deflector option)
	Hydrant fill
	20m 19mm spring rewind hose reel

Description

The TTI FirePatrol[™] is designed to carry and distribute water using a self-contained pump and various water dispensing systems. The FirePatrol[™] has the following features, refer to Figure 1.




Figure 1 – Component Identification

Tank

All TTI tanks are constructed from UV resistant, virgin material polyethylene. Due to the rotational moulding process, there may be a small variance in the overall dimensions of the tank, therefore, calibration markings should be used as a guide only.

LiquidLocker Safety Baffle System

The LiquidLocker[™] baffle system within the tank demonstrates measurable improvements in braking performance and dynamic stability and controllability. The system has been independently tested, with the report available upon request.

Tank Level Indicator

An optional sight level tube is fitted to the rear of the tank and provides an accurate level indication of water within the tank.

Pressure Regulator

A pressure regulator is fitted to the pump discharge flange to control line pressure and prevent pump cavitation. The factory-set regulator feeds excess water back to the tank and is set to relieve at 50 – 60 psi.

Hose Reel

Each FirePatrol[™] is fitted with a 36m 19mm diameter fire hose mounted on a manually operated hose reel. The hose is fitted with an adjustable nozzle which locates in a securing bracket on the hose reel support when the hose is stowed. The nozzle adjusts from closed through to jet and mist sprays, depending on requirement.

A spring rewind 20m hose reel is available as an option.

Pump

The FirePatrol™ is fitted with a twin impeller Davey firefighting pump as standard. The pump is coupled to a Honda GX200 engine or optional Yanmar diesel engine. The petrol engine is recoil (pull) start with local or remote electric start upgrade options available. The diesel engine is electric start with a remote start option available.

Batteries

With optional electric brakes installed on the FirePatrol™ trailer, a dedicated 12-volt battery is mounted at the front of the tank, housed in a battery box.

With the optioned electric pump start upgrade, a separate, dedicated 12-volt battery is installed behind the hose reel. Power to start the pump is always provided by this battery.

Quick Fill Hose Kit

Each FirePatrol™ is fitted with a front-mounted hose bracket, housing the 6m quick fill hose. The hose is fitted with a filter at one end and a camlock coupling on the opposite end, for direct connection to the pump.

Hydrant Fill Kit

An optional hydrant fill kit is available, which feeds directly into the top of the tank, with a camlock coupling to directly connect to a hydrant hose.

Trailer

The trailer frame is an all steel, fully welded construction and hot dip galvanised for corrosion resistance. The frame has additional welded gussets for added strength and filled-in chequer plate mudguards to protect the tank. Single and dual 50mm solid axle units, depending on tank capacity, fitted with 6-stud 15' Sunraysia wheels.

The trailers are available as unbraked or braked (registerable), with hydraulic or electric brakes, depending on tank capacity. The electric braked version has its own dedicated 12-volt battery located at the front of the trailer, and incorporates a break-away safety system, refer to Figure 2.

Deflector Spray Head

Optional single water deflector spray head or dual deflector spray heads are available. Each deflector spray head is fitted with its own dedicated ball valve for individual operation. An optional solenoid actuated valve enables the dual water deflector spray head system to be activated via the remote control unit.

Each of the dual deflectors are mounted on a hot dip galvanised steel manifold fed directly from the pump outlet manifold via a high pressure flexible hose, which absorbs vibration from the pump. The single deflector spray head is connected directly the pump outlet manifold via a flexible hose.

Each deflector spray head is secured with a camlock fitting, allowing removal for cleaning and adjustment for water spray direction.

Ball Control Valves

The FirePatrol™ has several ball control valves (depending on options) used to open or close water flow from the pump to the discharge points (hose reel and optional deflector spray head(s)). Ball control valves are also fitted on the suction line and the discharge side of the tank prior to entering the pump.

Solenoid Valve

An optional electrically operated solenoid valve is fitted to the deflector manifold to enable spray control via the remote control unit. The solenoid valve receives its power from the tow vehicle via the Anderson plug located adjacent to the tow hitch. Where the FirePatrol[™] is fitted with the electric start option, the solenoid valve may be operated by selecting the SELF POWERED position on the three-way switch of the control box mounted at the rear of the FirePatrol[™]. This should only be used where power is not available via the Anderson plug from the tow vehicle.

Remote Control Unit

An optional remote control unit enables the operator to start the optional dual water deflector spray system while in the tow vehicle's cab. If the optional petrol or diesel pump with electric start is fitted, the remote control unit enables pump start and stop, in addition to the water deflector spray system operation.

Machine Limitations

The FirePatrol[™] unit is subject to operating limitations. It is the operators' responsibility to ensure that this equipment is being operated safely and within these limitations.

Driving Stability

The FirePatrol[™] unit is heavy when filled with water. To maintain stability while operating this unit:

- Ensure the trailer tyres are inflated to their correct pressure at all times. Underinflated tyres can cause excessive lateral motion of the tyre, which may cause a rollover.
- Allow extra room for braking and turning when the tank is full.
- Ensure any side gradient (slope) is accounted for, especially when the FirePatrol[™] tank is full, as the unit will have a higher centre of gravity.

Operating Instructions

Before first use


Your FirePatrol[™] Firefighting Heavy-Duty Trailer Unit is delivered fully assembled. Before use, it needs to be set up using the following instructions:

1. Complete the warranty registration online at www.tti.com.au/warranty-registration, or use the Warranty Registration Card at the back of this handbook.
2. Store this handbook, along with the Tank Quality Check Form and pump unit's manual in the provided leather pouch, in a safe and easily accessible place for future reference.




WARNING: The operator must fully understand all aspects of this handbook. Do not operate the FirePatrol[™] if you are unfamiliar with its operation until you have read this handbook.

3. Read and thoroughly understand this handbook, paying particular attention to all safety requirements, before using the FirePatrol[™] for the first time.
4. Check that all fittings, valves, hoses and electrical leads are secure following transit, and are not damaged in any way.
5. Inspect the tank for any damage or abrasions.
6. Connect the FirePatrol[™] to the tow vehicle, ensuring the tow hitch engages correctly and locks in place. Connect the safety chains using rated D-shackles.
7. Connect the 7-pin trailer plug to the tow vehicle, ensuring it locks firmly. Ensure the AUX pin is supplied with 12-volt power from the tow vehicle, as this is essential for the electric brake safety unit, refer to Figure 2. Check lights and indicators operate correctly.
8. If fitted, connect the FirePatrol's Anderson plug socket to the tow vehicle for power supply to the optional solenoid operated ball valve, refer to Figure 2.



Anderson Plug Socket

Brake Safety Unit



7-Pin Plug Wiring Requirements

Figure 2 – Anderson Plug, Brake Safety Unit and 7-Pin Plug



WARNING: The engine must be inspected and prepared in accordance with the manufacturer. Failure to fulfil this requirement may void the engine's warranty.

9. Prepare the pump engine in accordance with the selected engine's manual supplied with your FirePatrol[™] unit.
10. Where an electric start petrol option or diesel pump is fitted, ensure the 12-volt battery is fully charged and correctly connected to the pump unit's engine. The battery box is located behind the hose reel. Refer to the supplied pump unit's manual and prepare the engine for use, such as filling its tank with fuel.

Pump Operation – Petrol Engine

The FirePatrol's petrol pump engine is started as follows, refer to Figure 3:

1. Turn the fuel lever to ON.
2. If the engine is cold, turn the choke lever to ON.



CAUTION: Ensure the engine's throttle is set to idle if the engine is cold. Do not adjust the throttle to maximum speed until the engine has warmed up.

3. Set the throttle lever to idle for cold starting. If restarting a warm engine, the throttle can be left at normal engine operating speed.
4. For a manual start engine, turn the power switch to ON. Pull the recoil starter handle until the engine starts, then back off the choke lever to OFF.

For an optional electric start engine, insert the key and switch the engine to ON and START. When the engine starts, release the key, which will return to the ON position. Back off the choke lever to OFF.

For an optional electric start engine using the remote control, insert the key and switch the engine to ON. Press and hold the No. 1 button of the remote control unit for several seconds. When the engine starts, release the pushbutton and back off the choke lever to OFF.

5. Once the engine is warmed up, adjust the throttle to increase the engine speed to normal operating revs.
6. When the engine needs to be stopped, turn the power (manual start) or key switch (electric start) to the OFF position. For the remote control option, press the No. 2 button.

If the FirePatrol[™] is not going to be used within the next few hours, shut the system down by turning the fuel tap to OFF.




Figure 3 – Engine Start-up (Petrol Engine shown)

Pump Operation – Diesel Engine Option

The FirePatrol's optional diesel pump engine is started as follows, refer to Figure 3:

1. Turn the fuel tap to ON.



CAUTION: Ensure the engine's throttle is set to the start position. Do not adjust the throttle to maximum speed until the engine has warmed up.

2. Set the throttle lever to the START or RUN position (depending on model).
3. Insert the key and switch the engine to ON and START. When the engine starts, release the key, which will return to the ON position.

For an optional electric start engine using the remote control, insert the key and switch the engine to ON. Press the No. 1 button of the remote control unit to turn the ignition ON, then press and hold No. 2 button for several seconds. When the engine starts, release the pushbutton.

4. Once warmed up, adjust the engine speed to normal operating revs.
5. When the engine needs to be stopped, turn the throttle/start lever (manual start) or key switch (electric start) to the OFF position. For the remote control option, press the No. 1 button to turn the ignition OFF.

If the FirePatrol[™] is not going to be used within the next few hours, shut the system down by turning the fuel tap to OFF.

Filling the Tank

The FirePatrol[™] tank can be filled in any of the following three ways:



CAUTION: The FirePatrol[™] unit is designed for water use only. It must not be used for chemicals or fuel.

1. Standpipe filling method using a standpipe to fill directly into the top of the tank via the open mesh funnel.
2. Bottom filling method, using the pump to draw water from a dam or other source.
3. Optional hydrant filling method, drawing pressurised water directly from a hydrant via the filling hose.

Standpipe Filling Operation

The FirePatrol[™] tank is filled by gravity from an overhead standpipe as follows:

1. Position the FirePatrol[™] unit's top-mounted fill point funnel under the standpipe.
2. Remove the filling lid from the tank's top opening.
3. Open the standpipe's valve and allow water to flow into the tank.



CAUTION: To prevent overflow, do not leave the filling operation unattended.

4. An optional sight level tube is fitted to the rear of the tank, providing a visual indicator of the level of water in the tank. If a sight level tube is not fitted, observe the water level directly in the tank. When the tank is filled, close the standpipe's valve.
5. Upon completion of filling, replace the tank's filling lid.

Bottom Filling Operation

The tank is filled by drawing water using the FirePatrol's pump as follows, referring to Figure 4:



CAUTION: Ensure all ball valves have been correctly set prior to commencing the filling operation, and that all camlock fittings are securely engaged and fully locked.

1. Ensure the ball valve on the suction line from the bottom of the tank to the pump is closed.
2. Remove the camlock cap from the discharge port of the pump.
3. Release the camlock fittings and disconnect the suction line from the pump, then connect it to the pump's discharge manifold port above.
4. A bottom fill supply hose is located on its bracket at the front of the FirePatrol's trailer. Remove it from the bracket and attach the camlock end to the pump's suction port.
5. Place the filter end of the bottom fill hose into the water source. Ensure the filter is deep enough in the water to prevent it sucking air.
6. Open the ball valve on the suction line from the bottom of the tank – this line is now connected to the pump's discharge port.
7. If required, prime the pump by unscrewing the cap at the top of the pump and fill it with water. Once full, replace the cap and tighten firmly.
8. Referring to Pump Operation procedures (diesel or petrol engine), start the pump.
9. Ensure the pump is drawing water and discharging it into the FirePatrol's tank.



CAUTION: To prevent overflow, do not leave the filling operation unattended

10. An optional sight level tube is fitted to the rear of the tank, providing a visual indicator of the level of water in the tank. If a sight level tube is not fitted, observe the water level directly in the tank. When the tank is filled, stop the pump.
11. Close the ball valve on the line to the bottom of the tank.
12. Disconnect the bottom fill supply hose from the pump's suction port.
13. Disconnect the tank's suction line from the pump's discharge port and reconnect it to the pump's suction port.
14. Reinstall the camlock cap to the pumps' discharge manifold.
15. Open the tank valve.
16. Drain and clean the hose and return it to its stowage bracket at the front of the trailer.




Figure 4 – Tank Filling Operation

Hydrant Filling Operation

The FirePatrol[™] tank is filled from a hydrant via the optional hydrant fill system as follows, referring to Figure 5:

1. Attach one end of a 3" hydrant hose (not supplied) to the FirePatrol's hydrant port, the other end to the hydrant.
2. Remove the tank's filling lid from the top of the tank.
3. Open the supply hydrant's valve slowly; water will flow under pressure through the FirePatrol's pipe system into the top of the tank.



CAUTION: To prevent overflow, do not leave the filling operation unattended.

4. An optional sight level tube is fitted to the rear of the tank, providing a visual indicator of the level of water in the tank. When the tank is filled, close the supply hydrant's valve.
5. Replace the filling lid.
6. Disconnect the hydrant supply hose and stow it.




Figure 5 – Hydrant Filling Operation (optional fill kit)

FirePatrol[™] Operation

Initial Operation Set Up

The FirePatrol[™] Multi-purpose Heavy-Duty Trailer Unit is operated as follows:

1. Connect the unit to the tow vehicle and check security of all connections (refer to Before First Use procedure above).
2. Fill the tank from an appropriate water source, refer to the Filling the Tank procedure above.
3. Open the ball valve on the suction hose at the bottom of the tank.
4. Start the pump (referring to the procedure above) and allow to warm up. The regulator (bypass valve) fitted to the top of the pump will divert the water back into the tank.

Fire Hose Use

With the FirePatrol[™] unit operating as described above, the fire hose is used as follows, refer to Figure 6:

1. Unlock the hose reel and release the hose's nozzle from its retaining bracket. Pull out the length of fire hose required.
2. Adjust the pump engine's speed to achieve the optimum flow rate.
3. Open the fire hose's nozzle by rotating it to achieve the desired spray pattern.
4. Upon completion of the task, close the fire hose nozzle and turn the pump engine to OFF, referring to the appropriate Pump Operation procedure above.
5. Open the fire hose nozzle again to release the residual pressure.
6. Rewind the hose onto the reel by manually winding the handle on the side of the reel. Close the nozzle and lock the nozzle back into its bracket.
7. Close the ball valve on the suction hose at the bottom of the tank.



Figure 6 – Fire Hose Reel

Water Deflector Spray Head

The FirePatrol[™] can be optionally fitted with a single, centrally mounted water deflector spray head, or a dual deflector spray head system mounted across the back of the unit. The dual system has a deflector spray head located at each corner. These systems may be used for dust suppression or similar watering activities.



CAUTION: The solenoid is electrically active when in use. Ensure it is switched to the POWERED position at the three-way switch.

If fitted with the optional solenoid actuated valve, move the three-way switch at the rear of the FirePatrol[™] from OFF to the POWERED position, refer to Figure 7. This will draw power from the tow vehicle via the Anderson plug. If power is not available, move the switch to the SELF POWERED position. This will draw power from the pump engine's battery. Using this battery should only be for short periods as the battery has limited charging capacity.



Figure 7 – Solenoid Control Switch

The optional single, centrally mounted deflector spray head is operated as follows:

1. If required, release the camlock connector to rotate the deflector spray head to the desired angle, refer to Figure 8. Lock the spray head back into place, ensuring the camlock levers are fully home.
2. Start the FirePatrol's pump system as described above.
3. For manual operation of the deflector spray head, open the ball valve. Water will spray from the deflector. Where the optional solenoid actuated valve is fitted, press button No.3 on the remote control. Water will spray from the deflector.
4. Commence driving the tow vehicle at a moderate speed to achieve the required water coverage.
5. Upon completion, stop the vehicle and shut the pump down.
6. Close the deflector spray head's ball valve.
For the solenoid actuated valve, press button No. 3 on the remote control to close the valve.
7. Close the ball valve on the suction hose at the bottom of the tank.
8. For the solenoid actuated valve option, move the three-way switch to the OFF position.



Figure 8 – Water Deflector Spray Head (optional)

The optional dual deflector spray head system is operated as follows:

1. If required, release the camlock connector to rotate the deflector spray head to the desired angle, refer to Figure 8. Lock the spray head back into place, ensuring the camlock levers are fully home.
2. Start the FirePatrol's pump system as described above.
3. At each deflector spray head, open the ball valve. Water will spray from the deflector.

Where the optional solenoid actuated valve is fitted, press button No.3 on the remote control. Water will spray from the deflector/s.

4. Commence driving the tow vehicle at a moderate speed to achieve the required water coverage.
5. For the solenoid actuated valve, press button No. 3 on the remote control to close the valve.
6. Upon completion, stop the vehicle and shut the pump down.
7. Close each of the deflector spray head's ball valves.
8. Close the ball valve on the suction hose at the bottom of the tank.
9. For the solenoid actuated valve option, move the three-way switch to the OFF position

Risk Assessment

Task	Hazard	Risk	Control Measure/Mitigation
Partially fill the tank with water, start the motor & test the spray unit	Manual handling; slips, trips or falls; petrol; diesel; fumes; fingers jammed	Medium	Concentrate on task; follow safe manual handling techniques: <ul style="list-style-type: none"> • Don't lift on your own if > 20kg, bend knees & keep back straight; Keep fingers clear; • Keep unit at least 8m away from overhead powerlines; • Fire extinguisher nearby; • Follow warning stickers on tanks; Wear PPE for petrol & diesel fumes-mask & gloves.
Check weather conditions	Manual handling; slips, trips or falls	Low	<ul style="list-style-type: none"> • Follow safe manual handling techniques: don't lift on your own if >20kg, bend knees & keep back straight.
Use spray or fire fighter units.	As above; loss of load; heat & cold; noise; exceed load limit of vehicle; hose entanglement; exhaust fumes; terrain & slopes; run over by unit	High	As above; <ul style="list-style-type: none"> • Wear clothes to suit heat & cold; • Wear hearing protection if noise >85 dBA; • Follow the manufacturer's safe operation instruction for the vehicle and the spray unit • Don't overload - water weighs 1kg for every 1 litre • Secure unit to tow vehicle; • Keep hose tidy; • Put unit brakes on (if fitted).
Clean up, maintenance & storage	As above	Low	As above; <ul style="list-style-type: none"> • Wear PPE for clean up; • Store unit in a dry, well ventilated area.
Burn risk	Hot exhaust/muffler Med	Med	<ul style="list-style-type: none"> • Do not reach over hot exhaust • Do not service engine while hot • Wear appropriate PPE

Maintenance

Your FirePatrol[™] Heavy-Duty Trailer Unit requires minimal maintenance but regular cleaning and checks will ensure safe and reliable service over its lifetime. Periodic checks and inspections will identify any potential issues, enabling timely rectification and minimising downtime.

Periodic Checks

The following checks and cleaning operations should be undertaken on a regular basis. The frequency of these activities will depend on the nature of the operating environment and the operational hours of the FirePatrol[™] unit. Refer to the maintenance schedule tables below for details of maintenance intervals.

1. Clean the unit and inspect it for any signs of damage or wear. Replace any safety labels if they are damaged or illegible.
2. Check all hoses, fasteners and fittings are firmly secured, tighten if necessary.
3. Unwind the hose from the reel fully to check that hose is in good order. Pressurise the line and check operation of spray nozzle. Rewind the hose onto the reel, ensuring it retracts all the way.
4. For the petrol or optional diesel engine driven pump, check the engine's oil level weekly. Top up as required.
5. Check for any signs of fuel or oil leaks. If detected, investigate and rectify immediately.
6. Check the condition of the optional diesel or petrol pump engine's 12 volt battery, replace it or charge it as necessary.
7. Check the condition of the optional electrical brake's 12 volt battery, replace it or charge it as necessary.
8. If the FirePatrol[™] is to be stored for an extended period, ensure the tank and all pipelines are empty and are not pressurised. Store the unit in a clean, dry and well-ventilated area.

Maintenance

The FirePatrol[™] has been designed and built for minimal maintenance requirements, however to ensure a long and reliable unit life, the following tasks must be undertaken on a periodic basis.



CAUTION: In dusty, dirty or smoky environments, cleaning, inspection and servicing of the unit on a regular basis is essential. The cleaning, inspection and servicing must be undertaken more frequently in harsh conditions to avoid damage or destruction of equipment.

The frequency of these activities will depend on the nature of the operating environment and the operational hours of the FirePatrol[™] unit.

For the petrol or optional diesel engine driven pump, refer to the supplied pump manual, drain and replace the engine oil in accordance with the manufacturer's recommendations.

Maintenance Schedule

The following tasks are to be conducted in accordance with each of the schedules. All scheduled tasks are to be undertaken concurrently. For example, at the three month maintenance interval, all task listed are to be undertaken, in addition to the daily, weekly and monthly tasks.



NOTE: Maintenance is important. Keep a record of all maintenance tasks conducted on the FirePatrol[™] unit.

TTi recommends photocopying these schedules in order to keep a detailed log of all maintenance tasks. A copy of these schedules will be required to support any warranty claim.

Daily Tasks

The following tasks are to be undertaken daily, or prior to each use, of the FirePatrol[™] unit.

No.	Task	Notes
1	Inspect the FirePatrol [™] for any signs of damage or wear	Clean, repair or replace
2	Check plug connections and test lights/indicators	Test function of lights and trailer brakes
3	Check fuel	Top up as required
4	Inspect engine's air filter and housing for dust	Clean, replace as necessary
5	Press button on brake safety unit (Figure 2) to test charge	Charge brake battery

Weekly Tasks

The following tasks are to be undertaken each week or 10 operating hours, whichever occurs first.

No.	Task	Date	Signed
1	All Daily tasks		
2	Remove and clean the engine's air filter		
3	Check engine oil level, top up as required		

Monthly Tasks

The following tasks are to be undertaken each month or 20 operating hours, whichever occurs first.

No.	Task	Date	Signed
1	All Daily and Weekly tasks		
2	Check tyre pressures are 36psi (248kPa or 2.48 Bar)		
3	Visually inspect tyres for wear or damage		
4	Check wheel nut tension		
5	Visually inspect suspension components		
6	Visually inspect hydraulic brake lines, check for leaks, top up reservoir as required		
7	Check for damaged electrical brake cables		
8	Check hose and hose reel by unwinding fully		
9	* Change pump engine oil (and filter, if fitted) (first change, thereafter every six months or 100 operating hours)		

Three Monthly Tasks

The following tasks are to be undertaken every three months or 50 operating hours, whichever occurs first.

No.	Task	Date	Signed
1	All Daily, Weekly and Monthly tasks		
2	* Re-tension axle U-bolts (first time, thereafter every six months or 100 operating hours)		
3	Inspect, clean and grease suspension lubrication points		
4	Inspect the air filter, replace if clogged or damaged		
5	Check all hoses, fasteners, nozzles and fittings		

Six Monthly Tasks

The following tasks are to be undertaken every six months or 100 operating hours, whichever occurs first.

No.	Task	Date	Signed
1	All Daily, Weekly, Monthly and 3-Monthly tasks		
2	Change engine oil (and filter, if fitted)		
3	Inspect spark plug (petrol engine only)		
4	Check tension on axle U-bolts and suspension components		
5	Lubricate grease nipples on suspension shackles and trailer hitch (hydraulic brake version)		

Twelve Monthly Tasks

The following tasks are to be undertaken every twelve months or 200 operating hours, whichever occurs first.

No.	Task	Date	Signed
1	All Daily, Weekly, Monthly, 3-Monthly & 6-Monthly tasks		
2	Check the battery condition (if fitted)		
3	Replace the engine's air filter		
4	Drain and flush the fuel tank		
5	Replace the engine's fuel filter		
6	Replace the spark plug (petrol engine only)		
7	Inspect brake shoe/pad wear and adjustment (if fitted)		

Two Yearly Tasks

The following tasks are to be undertaken every 24 months or 500 operating hours, whichever occurs first.

No.	Task	Date	Signed
1	All Daily, Weekly, Monthly, 3-Monthly, 6-Monthly and 12-Monthly tasks		
2	Disassembly, clean and repack wheel bearings		
3	Change brake fluid and bleed brakes (hydraulic braked version)		

Trouble Shooting

If a fault develops with the FirePatrol™, the following trouble shooting table provides guidance to identify and rectify the problem.

Problem	Possible Cause	Remedy
Pump will not feed water	Ball valve closed on outlet/s	Open ball valve/s
Engine will not crank (petrol or optional diesel engine)	Flat battery	Check battery state-of-charge
	Melted fusible link/circuit breaker	Replace fusible link/breaker
	Loose Connections	Clean and tighten connections
	Faulty Ignition Switch	Check switch operation, replace as needed
	Faulty magnetic, relay, neutral start or clutch switches	Check and replace as needed
	Mechanical problem in engine	Check Engine
	Problem in theft deterrent system	Check service manual for system tests
Engine cranks too slowly to start	Weak Battery	Check battery and charge as needed
	Loose or corroded connections	Clean and tighten connections
	Faulty starter motor	Test Starter
	Mechanical problems with engine or starter	Check engine and starter, replace worn out parts
Starter keeps running	Damaged pinion or ring gear	Check gears for wear or damage
	Faulty plunger in magnetic switch	Test starter pull-in and hold-in coils
	Faulty ignition switch or control circuit	Check switch and circuit components
	Binding ignition key	Check key for damage
Starter spins, but engine will not crank	Faulty over-running clutch	Check over-running clutch for proper operation
	Damaged or worn pinion gear or ring gear	Check gears for damage and wear; replace as needed
Starter does not engage/disengage properly	Faulty magnetic switch	Bench test starter
	Damaged or worn pinion gear or ring gear	Check gears for damage and wear; replace as needed

Warranty

Warranty Policy

TTi will, at its option, repair or replace without charge any part covered by this warranty which is found to be defective in material and/or workmanship within one (1) year after date of sale to the original retail purchaser. If the product is used for rental purposes, this warranty is limited to ninety (90) days.

Upon request, the customer will make the defective part available for inspection and/or return the defective part to TTi, transportation charges prepaid. All parts and components are covered by this warranty except the following, which are warranted separately by their respective manufacturers:

- engines
- gearboxes
- pumps
- regulators.

TTi does not assume any warranty obligation, liability or modification for these items, which are covered exclusively by the stated warranty of the respective manufacturers.

What this Warranty Does Not Cover?

This warranty does not cover:

This warranty does not cover:

1. defects caused by depreciation or damage caused by incorrect mounting, normal wear, accidents, improper maintenance, improper use or abuse of the product, alterations or failure to follow the instructions and warnings provided.
2. Any charges for making service calls, clean up time and transport charges.
3. The use of non-genuine parts on equipment supplied by TTi. This will automatically negate any warranty.

How to Obtain Service Under this Warranty?

Warranty service can be arranged by contacting your dealer, or by contacting TTi directly on 1800 816 277.

Proof of warranty registration and date of purchase may be required to verify warranty coverage. Any defective parts returned to TTi must be accompanied by a Return Goods Note. This form can be obtained by contacting Product Support on 1800 816 277 or emailing ProductSupport@tti.com.au.

Warranty Limitations

Warranty limitations are as follows:

1. There is no other express warranty. Any warranty that may be implied from this purchase including merchantability and fitness for purpose is hereby limited to the duration of this warranty and to the extent permitted by law. Any and all implied warranties are excluded.
2. TTi will not be liable for any incidental, consequential or special damages and/or expenses in connection with the purchase or use of this equipment, to the extent permitted by law.
3. Only the warranty expressed in this limited warranty shall apply and no dealer, distributor or individual is authorised to amend, modify, or extend this warranty in any way. Accordingly, additional statements, whether oral or written, do not constitute warranties by TTi, and should not be relied upon.



TransTank[®]
INTERNATIONAL



Scan to view our PDF
Handbook online

1800 816 277

sales@tti.com.au

PO Box 137, Nathalia, VIC, 3638

Murray Valley Hwy, Nathalia, VIC 3638

Proudly Built By:

Signature

Date

Quality Checked By:

Signature

Date

www.tti.com.au